

Instruction

		
4.5CM flat head screws	closure head	flange nut
A*18	C*4	D*4

Tips: Screw seven points tight during installation, and then tighten after all is completed.

Board name and serial number:



Step: 1



